


VUR 1109 (Graphite) and VUR 1110 (Pearl) Liberator Arm & Holder



- 1) Gently slide the arm through the hole in the Liberator. Note: Rib on top of arm **MUST** align with notch in hole of Liberator. Do **NOT** force.
- 2) Insert Arm Pin into any of the holes. Push pin **FIRMLY** into selected hole. Depending on which side you prefer, you might need to repeat step 1 above.
- 3) Your Liberator has two (2) slots for papers, documents, lists, messages, etc. You may easily adjust the Liberator angle or pivot out of the way when not in use.